

INSTALLATION INSTRUCTIONS FOR TABLE, PEDASTAL, AND STAND

(STANDARD on L-CLASS, and OPTIONAL on E-CLASS)



- TOOLS NEEDED:**
- CORDLESS DRILL
 - 1/8" DRILL BIT
 - #3 PHILIPS SCREW TIP
 - MASKING OR DUCT TAPE

INSTRUCTIONS:

1. Determine the location to mount the floor socket.
2. Apply tape to the drill bit, as a marker, so the bit does not exceed a depth of 3/4".
3. Pre-drill two (2) of the six (6) holes opposite of each other.
4. Install the two (2) #14 philips pan head screws.
5. Pre-drill the remaining four holes and install the screws.