



# POLYURETHANE FABRICS

## CARE & CLEANING GUIDE



**Step 1:** For light soiling, a solution of 10% mild soap and warm water, applied with a soft damp cloth. Rub gently and rinse with a water dampened cloth.

**Step 2:** For more difficult stains, dampen a soft white cloth with a solution of household bleach (10% bleach and 90% water). Rub gently and rinse with a water dampened cloth to remove bleach concentration.

**For Disinfecting:** Dampen a soft white cloth with a solution (5:1) of water and bleach. Rub gently and rinse with a water dampened cloth.

Any of the following solutions may be used as a cleaning agent:

- alcohol, water, and bleach (5:5:2)
- bleach and water (1:5)
- alcohol and water (1:1)

Most disinfectants will not damage Polyurethanes. All cleaners should be tested on a small, unobtrusive, area initially to confirm no immediate effect on color or product.

Certain clothing and accessory dyes (such as those used on denim jeans) may migrate to lighter colors. This phenomenon is increased by humidity and temperature and is irreversible. Please check compatibility when using this product in combination with painted or varnished surfaces.

3/30/16



# APPROVED CLEANERS



Cleaner	Cleaner's Manufacturer	Finish   Topcoat							
		PERMABLOK <sup>3®</sup> Grey Scale ISO 105-A03	Ag SILVERGUARD <sup>®</sup> SILVER ION TECHNOLOGY PERMABLOK <sup>3®</sup> Grey Scale ISO 105-A03	Acrylic Grey Scale ISO 105-A03	Napa Grey Scale ISO 105-A03	PBG <sup>+</sup> / PERMAGUARD <sup>®</sup>		Polyurethane (Dolce)	Polyurethane (Ballistic)
						Grey Scale ISO 105-A03	Stain Resistance		
303 Fabric / Vinyl Cleaner (dilution: 1/2 cup (4 oz) in 1 gallon water)	303 Products, Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4 Moderate Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
A&G Boat Wash & Multipurpose Cleaner (6:1 dilution)	A&G Industries, Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
All Purpose Vinyl Cleaner	CMI Vclean	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Asepticare TB + I I	Ecolab	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	Appreciable wear at Wyzen. 100K cycles - Not Approved	4.5 Slight Color Change
Babe's Boat Care Wash (dilution: 1 oz per gallon of water)	Babe's Boat Care Products	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Bio Kleen Amazing (dilution: 6 oz per gallon of water)	Bio Kleen Products Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4 Moderate Color Change	4 Moderate Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Caviwipes XL Packed	Metrex	4 Moderate Color Change	4 Moderate Color Change	4 Moderate Color Change	Discoloration Not Approved	4 Moderate Color Change	Class 4 No Staining	In Testing	In Testing
Crystal Simple Green (dilution 1:30)	Sunshine Makers, Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	4.5 Slight Color Change	In Testing
Coverage Plus Germicidal Wipes	Spray Nine	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	*4.5 Slight Color Change	*4.5 Slight Color Change
Dispatch (1:10 dilution)	Caltech Industries Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4 Moderate Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Ducky All Purpose Cleaner	Ducky Products, Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Stain Resistance Affected Not Approved	Stain Resistance Affected Not Approved	In Testing	In Testing

Cleaner results are rated on a scale of 1 - 5	1-3: Causes discoloration. Not recommended	4-5: *Recommended for use
---	--	---------------------------

\*Cleaners only recommended if diluted per manufacturer's instructions.

Topical cleaners must be wiped off with clean water and dried with clean cloth following application.

The performance results shown in this chart are not guaranteed for all SII Vinyl and Polyurethane products.

The evaluations are indicators after laboratory tests and may not be indicative of field performance.

Healthcare facilities maintain disinfecting regimens to reduce the spread of infections. There is a wide variety of available biocides that include bleaches, peroxides and quaternary ammonium products, among others. They should always be used at the recommended dilution, never in concentrated form.

To prolong the life of digital or any other coated fabric, they should be rinsed off after the recommended residence time. It should be noted that misuse of disinfectants is the major source of surface deterioration. Spradling continually evaluates cleaners/disinfectants.



# APPROVED CLEANERS



Cleaner	Cleaner's Manufacturer	Finish   Topcoat							
		PERMABLOK <sup>3®</sup> Grey Scale ISO 105-A03	Ag SILVERGUARD <sup>®</sup> SILVER ION TECHNOLOGY PERMABLOK <sup>3®</sup> Grey Scale ISO 105-A03	Acrylic Grey Scale ISO 105-A03	Napa Grey Scale ISO 105-A03	PBG <sup>+</sup> / PERMAGUARD <sup>®</sup> Grey Scale ISO 105-A03   Stain Resistance		Polyurethane (Dolce)	Polyurethane (Ballistic)
Fabric Cleaner	Tekonsha Corp.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Fanastatik® Antibacterial All Purpose Cleaner Heavy Duty	S.C. Johnson & Son, Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Formula 409® Antibacterial All-Purpose Cleaner	The Clorox Company	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Glance NA Diluted (1:50 water)	Diversey Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	Surface Damage - Not Approved	4.5 Slight Color Change
GP Forward Diluted (1:64 water)	Diversey Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	4.5 Slight Color Change	4.5 Slight Color Change
Hydrogen Peroxide Cleaner Disinfectant Wipes	Clorox	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	4.5 Slight Color Change	4.5 Slight Color Change
Lustrell Faux Leather Care Kit - Lustrell Regular Cleaner	Warwick Lustrell	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4 Moderate Color Change	4.5 Slight Color Change	N/A	In Testing	In Testing
Lysol Foaming Disinfectant Cleaner	Brand, IC	4 Moderate Color Change	4 Moderate Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	Appreciable wear at Wyzen. 100K cycles - Not Approved	4.5 Slight Color Change
Mold & Mildew Stain Remover dilution: 1 scoop (1/2 oz) per quart water	Iosso Marine Products	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	N/A	In Testing	In Testing
Mother's Leather Cleaner	Mothers	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Oxivir TB Wipes	Diversey Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4 Moderate Color Change	Surface spots & wear at Wyzen 100K Cycles - Not Approved	Surface spots & wear at Wyzen 100K Cycles - Not Approved	4.5 Slight Color Change	4.5 Slight Color Change

Cleaner results are rated on a scale of 1 - 5	1-3: Causes discoloration. Not recommended	4-5: *Recommended for use
---	--	---------------------------

\*Cleaners only recommended if diluted per manufacturer's instructions.

Topical cleaners must be wiped off with clean water and dried with clean cloth following application.

The performance results shown in this chart are not guaranteed for all SII Vinyl and Polyurethane products.

The evaluations are indicators after laboratory tests and may not be indicative of field performance.

Healthcare facilities maintain disinfecting regimens to reduce the spread of infections. There is a wide variety of available biocides that include bleaches, peroxides and quaternary ammonium products, among others. They should always be used at the recommended dilution, never in concentrated form.

To prolong the life of digital or any other coated fabric, they should be rinsed off after the recommended residence time. It should be noted that misuse of disinfectants is the major source of surface deterioration. Spradling continually evaluates cleaners/disinfectants.



# APPROVED CLEANERS



Cleaner	Cleaner's Manufacturer	Finish   Topcoat							
		PERMABLOK <sup>3</sup> Grey Scale ISO 105-A03	Ag SILVERGUARD <sup>®</sup> SILVER ION TECHNOLOGY PERMABLOK <sup>3</sup> Grey Scale ISO 105-A03	Acrylic Grey Scale ISO 105-A03	Napa Grey Scale ISO 105-A03	PBG <sup>+</sup> / PERMAGUARD <sup>®</sup>		Polyurethane (Dolce)	Polyurethane (Ballistic)
						Grey Scale ISO 105-A03	Stain Resistance		
Oxycide Diluted - 3 oz/gl in water	Ecolab	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Sanicloth AF 3	PDI	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Simple Green Towels	Simple Green	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4 Moderate Color Change	Class 4 No Staining	4.5 Slight Color Change	4.5 Slight Color Change
Stride Floral Neutral (1:32 water) - Daily clean (1:64 water - Clean excess dirt)	Diversey Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	4.5 Slight Color Change	4.5 Slight Color Change
Stride Fragrance Free Neutral Cleaner (1:266 water)	Diversey Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Super S	Tekonsha Corp.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	Surface damage - Not Approved	4.5 Slight Color Change
Super Sani-cloth	PDI	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing
Vinyl Sauce	Boat Bling	4 Moderate Color Change	4 Moderate Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	Appreciable wear at Wyzen. 100K cycles - Not Approved	4.5 Slight Color Change
Virex II 256 (1:256 dilution)	Diversey Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	Discoloration - Not Approved	Discoloration - Not Approved
Virox 5 Rtu	Diversey Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	Discoloration - Not Approved	Discoloration - Not Approved
Wex Cide 128 (1:128 dilution)	Wexford Labs, Inc.	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	4.5 Slight Color Change	Class 4 No Staining	In Testing	In Testing

Cleaner results are rated on a scale of 1 - 5	1-3 : Causes discoloration. Not recommended	4-5 : *Recommended for use
---	---	----------------------------

\*Cleaners only recommended if diluted per manufacturer's instructions.

Topical cleaners must be wiped off with clean water and dried with clean cloth following application.

The performance results shown in this chart are not guaranteed for all SII Vinyl and Polyurethane products.

The evaluations are indicators after laboratory tests and may not be indicative of field performance.

Healthcare facilities maintain disinfecting regimens to reduce the spread of infections. There is a wide variety of available biocides that include bleaches, peroxides and quaternary ammonium products, among others. They should always be used at the recommended dilution, never in concentrated form.

To prolong the life of digital or any other coated fabric, they should be rinsed off after the recommended residence time. It should be noted that misuse of disinfectants is the major source of surface deterioration. Spradling continually evaluates cleaners/disinfectants.